



SDM630-Mbus V2

DIN Rail Smart Meter for Single and Three Phase Electrical Systems



- Measures kWh Kvarh, KW, Kvar, KVA, P, F, PF, Hz, dmd, V, A, etc.
- Bi-directional measurement IMP & EXP
- Two pulse outputs
- Mbus
- Din rail mounting 35mm
- 100A direct connection
- Better than Class 1 / B accuracy

USER MANUAL

2016 V1.2

Introduction

The SDM630-Mbus V2 measures and displays the characteristics of single phase two wires (1p2w), three phase three wires (3p3w,) and three phase four wires(3p4w) supplies, including voltage, frequency, current, power ,active and reactive energy, imported or exported. Energy is measured in terms of kWh, kVAh. Maximum demand current can be measured over preset periods of up to 60 minutes. In order to measure energy, the unit requires voltage and current inputs in addition to the supply required to power the product.

SDM630-Mbus V2 supports max. 100A direct connection, saves the cost and avoid the trouble to connect external CTs, giving the unit a cost-effective and easy operation. Built-in interfaces provides pulse and Mbus outputs. Configuration is password protected.

Unit Characteristics

The Unit can measure and display:

- Line voltage and THD% (total harmonic distortion) of all phases
- Line Frequency
- Currents, Current demands and current THD% of all phases
- Power, maximum power demand and power factor
- Active energy imported and exported
- Reactive energy imported and exported

The unit has password-protected set-up screens for:

- Changing password
- Supply system selection 1p2w, 3p3w,3p4w
- Demand Interval Time(DIT)
- Reset for demand measurements
- Pulse output duration

Two pulse output indicates real-time energy measurement. An RS485 output allows remote monitoring from another display or a computer.

Mbus

This uses an MBus port with EN13753-3 protocol to provide a means of remotely monitoring and controlling the Unit.




Set-up screens are provided for setting up the MBus port.

Pulse output

This provides two pulse outputs that clock up measured active and reactive energy. The constant of pulse output 2 for active energy is 400imp/kWh (unconfigurable), its width is fixed at 100ms.

The default constant of configurable pulse output 1 is 400imp/kWh, default pulse width is 100ms.The configurable pulse output 1 can be set from the set-up menu.





Start-up Screens

| | | |
|---|--|--|
| 1 |  | The first screen lights up all display segments and can be used as a display check |
| 2 |  | The second screen indicates the firmware installed in the unit and its build number. |
| 3 |  | The interface performs a self-test and indicates the result if the test passes. |

After a short delay, the screen will display active energy measurements.

Measurements






The buttons operate as follows:


| | | |
|---|---|---|
| 1 |  | Selects the Voltage and Current display screens In Set-up Mode, this is the "Left" or "Back" button. |
| 2 |  | Select the Frequency and Power factor display screens In Set-up Mode, this is the "Up" button |
| 3 |  | Select the Power display screens In Set-up Mode, this is the "Down" button |
| 4 |  | Select the Energy display screens In Set-up mode, this is the "Enter" or "Right" button |

Voltage and Current







Each successive pressing of the  button selects a new range:

| | | |
|-----|---|-------------------------------------|
| 1-1 |  | Phase to neutral voltages(3p4w) |
| 1-2 |  | Phase to neutral voltages(3p3w) |
| 2 |  | Current on each phase |
| 3-1 |  | Phase to neutral voltage THD%(3p4w) |
| 3-2 |  | Phase to neutral voltage THD%(3p3w) |

| | | |
|---|---|-----------------------------|
| 4 |  | Current THD% for each phase |
|---|---|-----------------------------|

Frequency and Power factor and Demand

Each successive pressing of the  button selects a new range:

| | | |
|---|---|------------------------------------|
| 1 |  | Frequency and Power Factor (total) |
| 2 |  | Power Factor of each phase |
| 3 |  | Maximum Power Demand |
| 4 |  | Maximum Current Demand |

Power



Each successive pressing of the button select a new range:






| | | |
|---|--|--------------------------------------|
| 1 | | Instantaneous Active Power in kW |
| 2 | | Instantaneous Reactive Power in kVAr |
| 3 | | Instantaneous Volt-amperes in kVA |
| 4 | | Total kW, kVArh, kVA |

Energy Measurements



Each successive pressing of the button selects a new range:

| | | |
|-----|--|-------------------------------|
| 1-1 | | Imported active energy in kWh |
|-----|--|-------------------------------|


| | | |
|-----|--|-----------------------------------|
| 1-2 |  <p>The LCD display shows the word "EXPORT" in a small box at the top right. Below it, the digits "0000" are displayed on the top row and "00.00" on the bottom row. The unit "kWh" is shown to the right of the digits.</p> | Exported active energy in kWh |
| 2-1 |  <p>The LCD display shows the word "IMPORT" in a small box at the top center. Below it, the digits "0000" are displayed on the top row and "00.00" on the bottom row. The unit "kVArh" is shown to the right of the digits.</p> | Imported reactive energy in kVArh |
| 2-2 |  <p>The LCD display shows the word "EXPORT" in a small box at the top right. Below it, the digits "0000" are displayed on the top row and "00.00" on the bottom row. The unit "kVArh" is shown to the right of the digits.</p> | Exported reactive energy in kVArh |
| 3-1 |  <p>The LCD display shows a large "M" on the left side. To its right, the digits "0000" are on the top row and "031.4" are on the bottom row. The unit "kWh" is shown to the right of the digits.</p> | Total active energy in kWh |
| 3-2 |  <p>The LCD display shows a large "M" on the left side. To its right, the digits "0000" are on the top row and "00.00" are on the bottom row. The unit "kVArh" is shown to the right of the digits.</p> | Total reactive energy in kVArh |

Set-up

To enter set-up mode, pressing the  button for 3 seconds, until the password screen appears.



Setting up is password-protected so you must enter the correct password (default '1000') before processing. If an incorrect password is entered, the display will show: Err






To exit setting-up mode, press  repeatedly until the measurement screen is restored.



Set-up Entry Methods


Some menu items, such as password, require a four-digit number entry while others, such as supply system, require selection from a number of menu options.




Menu Option Selection

1) Use the  and  buttons to select the required item from the menu. Selection does not roll over between bottom and top of list

2) Press  to confirm your selection

3) If an item flashes, then it can be adjusted by the  and  buttons. If not, there maybe a further layer.





4) Having selected an option from the current layer, press  to confirm your selection. The SET indicator will appear.

5) Having completed a parameter setting, press  to return to a higher menu level. The SET indicator will be removed and you will be able to use the  and  buttons for further menu selection.










6) On completion of all set-up, press  repeatedly until the measurement screen is restored.




Number Entry Procedure

When setting up the unit, some screens require the entering of a number. In particular, on entry to the setting up section, a password must be entered. Digits are set individually, from left to right. The procedure is as follows:

- 1) The current digit to be set flashes and is set using the  and  buttons
- 2) Press  to confirm each digit setting. The SET indicator appears after the last digit has been set.
- 3) After setting the last digit, press  to exit the number setting routine. The SET indicator will be removed.









Change password




| | | |
|-----|---|---|
| 1 |  | Use the  and  to choose the change password option |
| 2-1 |  | Press the  to enter the change password routine. The new password screen will appear with the first digit flashing |
| 2-2 |  | Use  and  to set the first digit and press  to confirm your selection. The next digit will flash. |

| | | |
|--|---|---|
| 2-3 |  | Repeat the procedure for the remaining three digits |
| 2-4 |  | After setting the last digit, SET will show. |
| <p>Press  to exit the number setting routine and return to the Set-up menu. SET will be removed</p> | | |







DIT Demand Integration Time

This sets the period in minutes over which the current and power readings are integrated for maximum demand measurement. The options are: 0, 5, 8, 10, 15, 20, 30, 60 minutes

| | | |
|-----|---|--|
| 1 |  | <p>From the set-up menu, use  and  buttons to select the DIT option. The screen will show the currently selected integration time.</p> |
| 2-1 |  | <p>Press  to enter the selection routine. The current time interval will flash</p> |
| 2-2 |  | <p>Use  and  buttons to select the time required.</p> |




| | | |
|---|---|---|
| 2-3 |  | Press  to confirm the selection. SET indicator will appear. |
| Press  to exit the DIT selection routine and return to the menu. | | |









Backlit set-up

| | | |
|---|--|---|
| 1 |  | <p>The backlit lasting time is settable Default lasting time is 60minutes For example, if it's set as 5, the backlit will be off in 5minutes from the last time operation on the meter.</p> |
| 2 |  | Press  to enter the selection routine. The current time interval will flash The options can be: 0(always on),5,10,30,60,120minutes |
| Use  and  buttons to select the time required. Press  to confirm the set-up, | | |

Supply System

Use this section to set the type of power supply being monitored.

| | | |
|---|---|---|
| 1 |  | From the Set-up menu, use  and  buttons to select the System option. The screen will show the currently selected power supply. |
|---|---|---|

| | | |
|--|--|--|
| 2-1 |  | Press  to enter the selection routine. The current selection will flash |
| 2-2 |  | Use  and  buttons to select the required system option: 1P2(W),3P3(W) ,3P4(W) |
| 2-3 |  | Press  to confirm the selection. SET indicator will appear. |
| Press  to exit the system selection routine and return to the menu. SET will disappear and you will be returned to the main Set-up Menu | | |

Pulse output




This option allows you to configure the pulse output 1. The output can be set to provide a pulse for a defined amount of energy active or reactive.








Use this section to set up the pulse output for:

Total kWh/ Total kVArh

Import kWh/Export kWh

Import kVArh/Export kVArh

| | | |
|---|---|---|
| 1 |  | From the Set-up menu, use  and  buttons to select the Pulse output option. |
|---|---|---|






| | | |
|---|---|--|
| 2-1 |  | Press  to enter the selection routine. The unit symbol will flash. |
| 2-2 |  | Use  and  buttons to choose kWh or kVArh. |
| On completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu. | | |





Pulse rate

Use this to set the energy represented by each pulse. Rate can be set to 1 pulse per dFt/0.01/0.1/1/10/100kWh/kVArh.



(It shows 1 impulse = 10kWh/kVArh)

| | | |
|---|---|---|
| 1 |  | From the Set-up menu, use  and  buttons to select the Pulse Rate option. |
| 2 |  | Press  to enter the selection routine. The current setting will flash. Note: When it's dFt, it means 2.5Wh/VArh |








Use  and  buttons to choose pulse rate. On completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu.

Pulse Duration

The energy monitored can be active or reactive and the pulse width can be selected as 200, 100(default) or 60ms.



(It shows pulse width of 200ms)

| | | |
|--|--|--|
| 1-1 | | <p>From the Set-up menu, use  and  buttons to select the Pulse width option.</p> |
| 1-2 | | <p>Press  to enter the selection routine. The current setting will flash.</p> |
| <p>Use  and  buttons to choose pulse width. On Completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu.</p> | | |

Communication

There is a Mbus port can be used for communication using Mbus protocol. For Mbus communication, parameters are selected from Front panel.

RS485 Address



(The range is from 001 to 250)

| | | |
|--|--|---|
| 1 | | From the Set-up menu, use and buttons to select the Address ID |
| 2-1 | | Press button to enter the selection routine. The current setting will be flashing. |
| 2-2 | | Use and buttons to choose Modbus Address(001 to 250) |
| 2-3 | | Mbus secondary address It ranges from 00 00 00 01 to 99 99 99 99 |
| On completion of the entry procedure, press button to confirm the setting and press | | |










button to return the main set-up menu.

Baud Rate










| | | |
|--|--|---|
| 1 | | <p>From the Set-up menu, use and buttons to select the Baud Rate option.</p> |
| 2-1 | | <p>Press to enter the selection routine. The current setting will flash.</p> |
| 2-2 | | <p>Use and buttons to choose Baud rate 0.3k, 0.6k, 1.2k, 2.4k, 4.8k, 9.6k Default is 2.4k</p> |
| <p>On completion of the entry procedure, press to confirm the setting and press to return to the main set up menu.</p> | | |


Parity

| | | |
|---|--|---|
| 1 | | <p>From the Set-up menu, use and buttons to select the Parity option.</p> |
|---|--|---|

| | | |
|---|---|--|
| 2-1 |  | Press  to enter the selection routine. The current setting will flash. |
| 2-2 |  | Use  and  buttons to choose Parity (EVEN / ODD / NONE) |
| On Completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu. | | |

Stop bits








| | | |
|--|---|--|
| 1 |  | From the Set-up menu, use  and  buttons to select the Stop Bit option. |
| 2-1 |  | Press  to enter the selection routine. The current setting will flash. |
| 2-2 |  | Use  and  buttons to choose Stop Bit (2 or 1) |
| On completion of the entry procedure, press  to confirm the setting and press | | |

 to return to the main set up menu.

Note: Default is 1, and only when the parity is NONE that the stop bit can be changed to 2.

CLR

The meter provides a function to reset the maximum demand value of current and power.

| | | |
|---|--|---|
| 1 |  | From the Set-up menu, use  and  buttons to select the reset option. |
| 2 |  | Press  to enter the selection routine. The MD will flash. |
| Press  to confirm the setting and press  to return to the main set up menu. | | |

Specifications

Measured Parameters

The unit can monitor and display the following parameters of a single phase two wire(1p2w), three phase three wire(3p3w) or four phase four wire(3p4w) supply.

Voltage and Current

Phase to neutral voltages 100 to 289V a.c. (not for 3p3w supplies)

Voltages between phases 173 to 500V a.c. (3p supplies only)

Basic current (I_b): 10A

Max current : 100A

Min. Current: 5% of I_b

Starting current: 0.4% of I_b

Percentage total voltage harmonic distortion (THD%) for each phase to N (not for 3p3w supplies)

Percentage voltage THD% between phases (three phase supplies only)

Current THD% for each phase

Power factor and Frequency and Max. Demand

Frequency in Hz

Instantaneous power:

Power 0 to 99999 W

Reactive Power 0 to 99999 VAR

Volt-amps 0 to 99999 VA

Maximum demanded power since last Demand reset Power factor

Maximum neutral demand current, since the last Demand reset (for 3p4w supply only)

Energy Measurements

- Imported active energy 0 to 999999.99 kWh
- Exported active energy 0 to 999999.99 kWh
- Imported reactive energy 0 to 999999.99 kVAh
- Exported reactive energy 0 to 999999.99 kVAh
- Total active energy 0 to 999999.99 kWh
- Total reactive energy 0 to 999999.99 kVAh

Measured Inputs

Voltage inputs through 4-way fixed connector with 25mm² stranded wire capacity. single phase two wire(1p2w), three phase three wire(3p3w) or four phase four wire(3p4w) unbalanced. Line frequency measured from L1 voltage or L3 voltage.

Accuracy

- Voltage 0.5% of range maximum
- Current 0.5% of nominal
- Frequency 0.2% of mid-frequency
- Power factor 1% of unity (0.01)
- Active power (W) $\pm 1\%$ of range maximum
- Reactive power (VAr) $\pm 2\%$ of range maximum
- Apparent power (VA) $\pm 1\%$ of range maximum
- Active energy (Wh) Class 1 IEC 62053-21
- Reactive energy (VARh) $\pm 2\%$ of range maximum
- Total harmonic distortion 1% up to 19th harmonic
- Temperature co-efficient Voltage and current = 0.013%/°C typical
Active energy = 0.018%/°C, typical
- Response time to step input 1s, typical, to >99% of final reading, at 50 Hz.

Interfaces for External Monitoring

Three interfaces are provided:

- an MBus communication channel that can be programmed for MBus EN13757-3 protocol
- an Pulse output(Pulse 1) indicating real-time measured energy.(configurable)
- an Pulse output(Pulse 2) 400imp/kWh

The Modbus configuration (Baud rate etc.) and the pulse output assignments (kW/kVArh, import/export etc.) are configured through the Set-up screens.

Pulse Output

The unit provides two pulse outputs. Both pulse outputs are passive type.

Pulse output 1 is configurable. The pulse output can be set to generate pulses to represent total / import/export kWh or kVarh.

The pulse constant can be set to generate 1 pulse per:

dFt = 2.5 Wh/VArh

0.01 = 10 Wh/VArh

0.1 = 100 Wh/VArh

1 = 1 kWh/kVArh

10 = 10 kWh/kVArh

100 = 100 kWh/kVArh

Pulse width: 200/100/60ms

Pulse output 2 is non-configurable. It is fixed up with active kWh. The constant is 400imp/kWh.

MBus Output for EN_13757-3

For MBus **EN13757-3**, the following MBus communication parameters can be configured from the Set-up menu:

Baud rate 300, 600, 1200, 2400, 4800, 9600

Parity none (default)/odd/even

Stop bits 1 or 2

MBus network primary address *nnn* – 3-digit number, 001 to 250

Mbus network secondary address 00 00 00 01 to 99 99 99 99(The secondary address can not be setted directly on meter, but can be done via Mbus communication)

Reference Conditions of Influence Quantities


Influence Quantities are variables that affect measurement errors to a minor degree. Accuracy is verified under nominal value (within the specified tolerance) of these conditions.

- Ambient temperature 23°C ±2°C
- Input frequency 50Hz/60Hz ±2%
- Input waveform Sinusoidal (distortion factor < 0.005)
- Magnetic field of external origin Terrestrial flux

Environment


- Operating temperature -25°C to +55°C*
- Storage temperature -40°C to +70°C*
- Relative humidity 0 to 90%, non-condensing
- Altitude Up to 2000m
- Warm up time 10s
- Vibration 10Hz to 50Hz, IEC 60068-2-6, 2g

Dimensions




Wiring diagram


- Three Phase Three Wires:



- Three Phase Four Wires:



- Single Phase two Wires:



-

SDM630 MBUS protocol V1.1

1. Initialization slave

Format:

| Start | C Field | A Field | Check Sum | Stop |
|-------|---------|---------|-----------|------|
| 10 | 40 | XX | CS | 16 |

XX=1 to FF

The address field serves to address the recipient in the calling direction, and to identify the sender of information in the receiving direction. The size of this field is one Byte, and can therefore take values from 0 to 255. The addresses 1 to 250 can be allocated to the individual slaves, up to a maximum of 250. Unconfigured slaves are given the address 0 at manufacture, and as a rule are allocated one of these addresses when connected to the M-Bus. The addresses 254 (FE) and 255 (FF) are used to transmit information to all participants (Broadcast). With address 255 none of the slaves reply, and with address 254 all slaves reply with their own addresses. The latter case naturally results in collisions when two or more slaves are connected, and should only be used for test purposes. The address 253 (FD) indicates that the addressing has been performed in the Network Layer instead of Data Link Layer, The FD used when using The second level address. The remaining addresses 251 and 252 have been kept for future applications.

1.1 How to initialize a meter which you don't know the address

Master to slave: 10 40 fe 3e 16

Slave to master: e5 (success)

1.2 Remove the secondary address matching symbol of all the meters on BUS.

Master to slave: 10 40 fd 3d 16

Slave: **No answer**

1.3 How to initialize all meters on the bus line by using FF as broadcast address

Master to slave: 10 40 ff 3f 16

Slave: **No answer**

1.4 How to Initialize a Slave with specific address

Example: Address 01

Master to slave : 10 40 01 41 16

Slave to master: e5

2. How to Set Baud rate

2.1 Point to point baud-rate setting command format (Control Frame)

| Start | L Field | L Field | Start | C Field | A Field | CI Field | Check Sum | Stop |
|-------|---------|---------|-------|---------|---------|--------------|-----------|------|
| 68H | 03 | 03 | 68H | 53/73 | Addr | b8~bd | CS | 16 |

L Field-----Byte length

C Field-----Control Field, Function Field

A Field -----Address Field

CI Field -----control information field

Check Sum-----The Check Sum is calculated from the arithmetical sum of the data mentioned above, without taking carry digits into account.

B8-----300

B9-----600

BA-----1200

BB-----2400

BC-----4800

BD-----9600

Example: (Meter address is 01)

(1) How to change Baud rate to 2400bps

Master to slave: 68 03 03 68 53 01 BB 0F 16

Slave to master: E5

(2) How to change Baud rate to 9600

Master to slave: 68 03 03 68 53 01 BD 11 16

Slave to master: E5

2.2 How to use Broadcast command to set baud rate

Format:

| Start | L Field | L Field | Start | C Field | A Field | CI Field | Check Sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----------|------|
| 68H | 03 | 03 | 68H | 53/73 | ff | b8~bd | CS | 16 |

Slave to master: no answer

B8-----300

B9-----600

BA-----1200

BB-----2400

BC-----4800

BD-----9600

Example:

Change all the meters' baud rate to 2400bps

Master to slave: 68 03 03 68 53 ff bb 0d 16

Slave to Master: No answer

3. How to Set primary address

3.1 How to set the address of a Slave to 01

Format:

| Start | L Field | L Field | Start | C Field | A Field | CI Field | DIF | VIF | Address Data | Check Sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----|-----|--------------|-----------|------|
| 68H | 06 | 06 | 68H | 53/73 | fe | 51 | 01 | 7A | XX | CS | 16 |

Example:

Master to slave: 68 06 06 68 53 fe 51 01 7a **01** 1e 16

Slave to master: e5

3.2 How to use Broadcast Command to set primary address to 01

Master to slave: 68 06 06 68 53 **ff** 51 01 7a **01** 1f 16

| Start | L Field | L Field | Start | C Field | A Field | CI Field | DIF | VIF | Address Data | Check Sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----|-----|--------------|-----------|------|
| 68H | 06 | 06 | 68H | 53/73 | ff | 51 | 01 | 7A | XX | CS | 16 |

Slave : **no answer**

3.3 How to change Address from 01 to 02

Format

| Start | L Field | L Field | Start | C Field | A Field | CI Field | DIF | VIF | Address Data | Check Sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----|-----|--------------|-----------|------|
| 68H | 06 | 06 | 68H | 53/73 | XX | 51 | 01 | 7A | YY | CS | 16 |

XX--current primary Address

YY--new primary address

Master to slave: 68 06 06 68 73 **01** 51 01 7A **02** 42 16

Slave to master: e5

3.4 How to set primary address to 01 by using secondary address

For example: secondary address: 12345678

Step1 Initialize the slave

Master to slave : 10 40 ff 3f 16

Slave to master: no answer

Step2 Check the secondary address. After receiving the command, the Slave will check if the secondary address in the command is same with its secondary address or not.

Maseter to slave: 68 0B 0B 68 73 **FD** 52 **78 56 34 12** FF FF FF FF D2 16

FD--- the primary Address used when you use secondary address to read data.

78 56 34 12 ---the meter's secondary address is 12 34 56 78

Master to slave: e5 (success)

Step3 Change the primary address to 01

Master to slave: 68 06 06 68 73 FD 51 01 7A **01** 3D

01---- new primary address

Slave to master: e5

4. Set the complete identification of the slave

(ID=12345678, Man=4024h (PAD), Gen=1, Med=02 (energy))

| Start | L Field | L Field | Start | C Field | A Field | CI Field | DIF | VIF | Identification No | Manufacturer ID | Generati-on | Medium | Check Sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----|-----|-------------------|-----------------|-------------|--------|-----------|------|
|-------|---------|---------|-------|---------|---------|----------|-----|-----|-------------------|-----------------|-------------|--------|-----------|------|

| | | | | | | | | | | | | | | |
|-----|----|----|-----|-------|------|----|----|----|--------|--------|--------|--------|----|----|
| 68H | 0D | 0D | 68H | 53/73 | addr | 51 | 07 | 79 | 4 byte | 2 byte | 1 byte | 1 byte | CS | 16 |
|-----|----|----|-----|-------|------|----|----|----|--------|--------|--------|--------|----|----|

For example: (Meter address is 01)

Master to slave: 68 0D 0D 68 53 01 51 07 79 78 56 34 12 24 40 01 02 A0 16

Slave to master: e5

5. How to read out of Energy information

5.1 Use primary address 01 to read Energy information

Format:

Master to slave: 10 7B/5B adr cs 16

Slave to master: Variable data structure

Example: 10 7B 01 7C 16

5.2 How to read out a meter’s Energy information by using broadcast address 254 (FE)

Master to slave: 10 7b/5b fe cs 16

Slave to master: Variable data structure

Example: 10 5B FE 59 16

5.3 How to read out the meter’s Energy information by using secondary Address

For example: Secondary address: 12 34 56 78

Step1 initialize the slave

Master to slave: 10 40 ff 3f 16

Slave to master: No answer

Step2 Check the secondary address. After receiving the command, the Slave will check if the secondary address in the command is same with its secondary address or not.

Master to slave: 68 0b 0b 68 73 fd 52 78 56 34 12 FF FF FF FF d2 16

Slave to master: E5

Step3 Read the Energy information

Master to slave: 10 7b fd 78 16

Slave to master:

DIF=====Coding of t e Data Information Field

VIF=====Codes for Value Information Field

| bytes | Parameters | data structure | Notice | |
|-------|-----------------|----------------|-----------------------------------|-----------|
| 4 | header telegram | 68 5d 5d 68 | eadar of RSP_UD telegram | |
| 3 | | 08 A 72 | C field =08 address A CI field 72 | |
| 4 | | 78 65 34 21 | Identification number =12345678 | |
| 2 | | 24 40 | Manufacturer ID 4024 | |
| 1 | | 01 | Generation 1 | |
| 1 | | 02 | Energy Meter | |
| 1 | | 55 | ACCESS NO | |
| 1 | | 00 | STATUS | |
| 1 | | 00 | 00 | Signature |
| 2 | | | 00 00 | |

| | | | |
|---|--|-------------|-----------------------------------|
| 6 | Current total active energy | 0C | DIF: 8digit BCD , Current Value |
| | | 04 | VIF: 10w (0.01Kw) |
| | | 78 56 34 12 | 123456.78kwh |
| 7 | Current import active energy (Readout is "0" if there is no this function) | 0C | DIF: 8digit BCDFIE, Current Value |
| | | 04 | VIF: 10w (0.01Kw) |
| | | 78 56 34 12 | 123456.78kwh |
| 7 | Current export active energy (Readout is "0" if there is no this function) | 0C | DIF: 8digit BCDFIE Current Value |
| | | 04 | VIF: 10w (0.01Kw) |
| | | 78 56 34 12 | 123456.78kwh |
| 6 | Current resettable total active energy (Readout is "0" if there is no this function) | 0C | DIF: 8digit BCD , Current Value |
| | | 04 | VIF: 10w (0.01Kw) |
| | | 78 56 34 12 | 123456.78kwh |
| 7 | Current resettable import active energy | 0C | DIF: 8digit BCDFIE, Current Value |
| | | 04 | VIF: 10w (0.01Kw) |
| | | 78 56 34 12 | 123456.78kwh |
| 7 | Current resettable export active energy | 0C | DIF: 8digit BCDFIE, Current Value |
| | | 04 | VIF: 10w (0.01Kw) |
| | | 78 56 34 12 | 123456.78kwh |
| 7 | Current total reactive energy | 0C | DIF: 8digit BCD , Current Value |
| | | FD | VIF: fd |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 78 56 34 12 | 123456.78kVarh |
| 8 | Current import reactive energy | 0C | DIF: 8digit BCDFIE, Current Value |
| | | FD | VIF: fd |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 78 56 34 12 | 123456.78kVarh |
| 8 | Current export reactive energy | 8C | DIF: 8digit BCDFIE Current Value |
| | | FD | VIF: fd |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 78 56 34 12 | 123456.78kVarh |
| 7 | Current total resettable reactive energy (Readout is "0" if there is no this function) | 0C | DIF: 8digit BCD , Current Value |
| | | FD | VIF: fd |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 78 56 34 12 | 123456.78kVarh |
| 8 | Current resettable import reactive energy (Readout is "0" if there is no this function) | 0C | DIF: 8digit BCDFIE, Current Value |
| | | FD | VIF: fd |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 78 56 34 12 | 123456.78kVar |
| 8 | Current resettable export reactive energy (Readout is "0" if there is no this function) | 0C | DIF: 8digit BCDFIE, Current Value |
| | | FD | VIF: fd |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 78 56 34 12 | 123456.78kVar |
| 1 | CHECK SUM | CS | |
| 1 | End | 16 | |

6. Read out of instantaneous electrical information

The instantaneous electrical information includes:

V , I , P , Q , S , PF , Hz ect. MD

6.1 How to read instantaneous electrical information by using primary address:

| Start | L Field | L Field | Start | C Field | A Field | CI Field | C eck Sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----------|------|
| 68 | 3 | 3 | 68 | 53/73 | XX | B1 | CS | 16 |

Master to slave: 68 03 03 68 53 **XX** b1 CS 16

Slave to master: Variable data structure (instantaneous electrical information)

If the primary address is 01 then XX=01

6.2 How to use Secondary Address to read out the instantaneous electrical information

Step1 Initialization slave

Master to slave: 10 40 ff 3f 16

Slave to master: No answer

Step2 Check the secondary address. After receiving the command, the Slave will check if the secondary address in

the command is same with its secondary address or not.

Master to slave: 68 0b 0b 68 73 fd 52 78 56 34 12 ff ff ff d2 16

Slave to master: E5

Step3 Use Secondary Address to read out the instantaneous electrical information

Master to slave: 68 03 03 68 53 **fd** b1 01 16

Slave to master: Variable data structure

| bytes | | data structure | Notice |
|-------|-----------------|----------------|-----------------------------------|
| 4 | header telegram | 68 90 90 68 | header of RSP_UD telegram |
| 3 | | 08 A 72 | C field =08 address A CI field 72 |
| 4 | | 78 65 34 21 | Identification number =12345678 |
| 2 | | 24 40 | Manufacturer ID 4024 |
| 1 | | 01 | Generation 1 |
| 1 | | 02 | Energy Meter |
| 1 | | 55 | ACCESS NO |
| 1 | | 00 | STATUS |
| 2 | | 00 00 | Signature |
| 6 | | L1 Voltage | 0b |
| | Fd | | VIF:fd |
| | 47 | | VIFE: 0.01V |
| | 56 34 12 | | 1234.56V |
| 6 | L2 Voltage | 0b | DIF: 6digit BCD |
| | | Fd | VIF:fd |
| | | 47 | VIFE: 0.01V |
| | | 56 34 12 | 1234.56V |
| 6 | L3 Voltage | 0b | DIF: 6digit BCD |
| | | Fd | VIF:fd |
| | | 47 | VIFE: 0.01V |
| | | 56 34 12 | 1234.56V |
| 6 | L1-L2 Voltage | 0b | DIF: 6digit BCD |
| | | Fd | VIF:fd |
| | | 47 | VIFE: 0.01V |
| | | 56 34 12 | 1234.56V |
| 6 | L2-L3 Voltage | 0b | DIF: 6digit BCD |

| | | | |
|---|----------------------|----------|------------------------------|
| | | Fd | VIF:fd |
| | | 47 | VIFE: 0.01V |
| | | 56 34 12 | 1234.56V |
| 6 | L3-L1 Voltage | 0b | DIF: 6digit BCD |
| | | Fd | VIF:fd |
| | | 47 | VIFE: 0.01V |
| | | 56 34 12 | 1234.56V |
| 6 | L1 current | 0b | DIF: 6digit BCD |
| | | Fd | VIF:fd |
| | | 59 | VIFE: 1mA(xxx.xxxA) |
| | | 56 34 12 | 123456mA(123.456A) |
| 6 | L2 current | 0b | DIF: 6digit BCD |
| | | Fd | VIF:fd |
| | | 59 | VIFE: 1mA(xxx.xxxA) |
| | | 56 34 12 | 123456mA(123.456A) |
| 6 | L3 current | 0b | DIF: 6digit BCD |
| | | Fd | VIF:fd |
| | | 59 | VIFE: 1mA(xxx.xxxA) |
| | | 56 34 12 | 123456mA(123.456A) |
| 6 | N current | 0b | DIF: 6digit BCD |
| | | Fd | VIF:fd |
| | | 59 | VIFE: 1mA(xxx.xxxA) |
| | | 56 34 12 | 123456mA(123.456A) |
| 5 | total active power | 0b | DIF: 6digit BCD |
| | | 2a | VIF:0.1W(xx.xxxxkw) |
| | | 56 34 12 | 12345.6w(12.3456kw) |
| 5 | L1 active power | 0b | DIF: 6digit BCD |
| | | 2a | VIF:0.1W(xx.xxxxkw) |
| | | 56 34 12 | 12345.6w(12.3456kw) |
| 5 | L2 active power | 0b | DIF: 6digit BCD |
| | | 2a | VIF:0.1W(xx.xxxxkw) |
| | | 56 34 12 | 12345.6w(12.3456kw) |
| 5 | L3 active power | 0b | DIF: 6digit BCD |
| | | 2a | VIF:0.1W(xx.xxxxkw) |
| | | 56 34 12 | 12345.6w(12.3456kw) |
| 6 | total reactive power | 0b | DIF: 6digit BCD |
| | | Fd | VIF:fd |
| | | 3a | VIFE: dimensionless / no VIF |
| | | 56 34 12 | 12345.6w(12.3456kw) |
| 6 | L1 reactive power | 0b | DIF: 6digit BCD |
| | | Fd | VIF:fd |
| | | 3a | VIFE: dimensionless / no VIF |
| | | 56 34 12 | 12345.6w(12.3456kw) |
| 6 | L2 reactive power | 0b | DIF: 6digit BCD |
| | | Fd | VIF:fd |
| | | 3a | VIFE: dimensionless / no VIF |
| | | 56 34 12 | 12345.6w(12.3456kw) |
| 6 | L3 reactive power | 0b | DIF: 6digit BCD |
| | | Fd | VIF:fd |
| | | 3a | VIFE: dimensionless / no VIF |
| | | 56 34 12 | 12345.6w(12.3456kw) |
| 5 | Total power factor | 0a | DIF: 4digit BCD |
| | | Fd | VIF:fd |
| | | 3a | VIFE: dimensionless / no VIF |
| | | 00 05 | 0.500 |

| | | | |
|---|----------------|-------|------------------------------|
| 5 | A power factor | 0a | DIF: 4digit BCD |
| | | Fd | VIF:fd |
| | | 3a | VIFE: dimensionless / no VIF |
| | | 00 05 | 0.500 |
| 5 | B power factor | 0a | DIF: 4digit BCD |
| | | Fd | VIF:fd |
| | | 3a | VIFE: dimensionless / no VIF |
| | | 00 05 | 0.500 |
| 5 | C power factor | 0a | DIF: 4digit BCD |
| | | Fd | VIF:fd |
| | | 3a | VIFE: dimensionless / no VIF |
| | | 00 05 | 0.500 |
| 5 | Frequency | 0a | DIF: 4digit BCD |
| | | Fd | VIF:fd |
| | | 3a | VIFE: dimensionless / no VIF |
| | | 00 50 | 50.00 z |
| 1 | End | CS | |
| 1 | | 16 | |

7. How to read password

| Start | L Field | L Field | Start | C Field | A Field | CI Field | Check Sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----------|------|
| 68 | 3 | 3 | 68 | 11 | addr | 03 | CS | 16 |

Master to Slave: 68 03 03 68 11 addr 03 cs 16

Slave to Master: 68 05 05 68 11 addr 03 password H password L cs 16

7.1 Change to a new Password

| Start | L Field | L Field | Start | C Field | A Field | CI Field | Data | Check Sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|---------------------|-----------|------|
| 68 | 5 | 5 | 68 | 11 | addr | 04 | Password Password L | CS | 16 |

Master to Slave: 68 05 05 68 11 addr 04 password H password L cs 16

Slave to Master: E5

8. How to reset all resettable energy data

| Start | L Field | L Field | Start | C Field | A Field | CI Field | Check Sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----------|------|
| 68 | 3 | 3 | 68 | 11 | addr | 0d | CS | 16 |

For example: addr: 01

Master to Slave: 68 03 03 68 11 01 0d 1f 16

Slave to Master: e5

9. Set Demand interval、slide time、Display time、LED time

Send: 68 09 09 68 53 FE 51 30 01 60 01 05 06 3F 16

| Start | L | L | Start | C | A | CI | DIF | VIF | data | Check | Stop |
|-------|---|---|-------|---|---|----|-----|-----|------|-------|------|
|-------|---|---|-------|---|---|----|-----|-----|------|-------|------|

| | Field | Field | | Field | Field | Field | | | | Sum | |
|-----|-------|-------|-----|-------|-------|-------|----|----|---|-----|----|
| 68H | 09 | 09 | 68H | 53/73 | FE | 51 | 30 | 01 | Demand interval、slide time、Display time、LED time Display time=0 : the display does not scroll automatically. LED time=0 :Backlight always on min-min-s-min 4 bytes | cs | 16 |

Example: (Meter address is 01)

Master to Slave: 68 09 09 68 53 FE 51 30 01 60 01 05 06 3F 16

Slave to Master: E5

10. Read Demand interval、slide time、Display time、LED time

| Start | L Field | L Field | Start | C Field | A Field | CI Field | DIF | VIF | Check Sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----|-----|-----------|------|
| 68H | 05 | 05 | 68H | 53/73 | FE | 51 | 30 | 81 | cs | 16 |

Example: (Meter address is 01)

Master to Slave: 68 05 05 68 53 FE 51 30 81 53 16

Slave to Master: E5

| Bytes | Parameters | Data structure | Notice |
|-------|-----------------|--|--|
| 4 | header telegram | 68 16 16 68 | header of RSP_UD telegram |
| 3 | | 08 A 72 | C field =08 address A CI field 72 |
| 4 | | 78 65 34 21 | Identification number =12345678 |
| 2 | | 24 40 | Manufacturer ID 4024 |
| 1 | | 01 | Generation 1 |
| 1 | | 02 | Energy Meter |
| 1 | | 55 | ACCESS NO |
| 1 | | 00 | STATUS |
| 2 | | 00 00 | Signature |
| 7 | | Demand interval、slide time、Display time、LED time | 0a |
| | Fd | | VIF:fd |
| | 3a | | VIFE: dimensionless / no VIF |
| | 15010610 | | Demand interval: 15 min slide time: 01min Display time: 06s LED time: 10s |
| 1 | CHECK SUM | CS | |
| 1 | End | 16 | |

11. Read the measurement mode

| Start | L Field | L Field | Start | C Field | A Field | CI Field | Check Sum | Stop |
|-------|---------|---------|-------|---------|---------|-----------|-----------|------|
| 68 | 03 | 03 | 68 | 11 | addr | 09 | CS | 16 |

Example: (Meter address is 01)

Master to Slave: 68 03 03 68 11 **01** 09 1b 16
 Slave to Master: 68 04 04 68 11 01 09 **01** 1c 16
 The red-lighted **01** represents the measurement mode
 01means Active energy
 02means Active energy+Reactive energy
 03means Active energy- Reactive energy

12. Set up the measurement mode

| Start | L Field | L Field | Start | C Field | A Field | CI Field | data | Check Sum | Stop |
|-------|---------|---------|-------|---------|---------|-----------|----------|-----------|------|
| 68 | 04 | 04 | 68 | 11 | addr | 0A | 01/02/03 | CS | 16 |

Example: (Meter address is 01)
 Master to Slave: 68 04 04 68 11 01 0A **01** 1c 16
 Slave to Master: e5
 The red-lighted **01** represents the measurement mode
 01 means Active energy
 02 means Active energy+Reactive energy
 03 means Active energy- Reactive energy

13. Read the output mode of Pulse 1

| Start | L Field | L Field | Start | C Field | A Field | CI Field | Check Sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----------|------|
| 68 | 03 | 03 | 68 | 11 | addr | 10 | CS | 16 |

Example: (Meter address is 01)
 Master to Slave: 68 03 03 68 11 01 10 22 16
 Slave to Master: 68 04 04 68 11 01 10 **01** 23 16
 The red-lighted **01** represents the output mode of Pulse1
 01: Import active energy,
 02: Import + export active energy,
 04: Export active energy (default).
 05: Import reactive energy,
 06: Import + export reactive energy,
 08: Export reactive energy,

14. Set up the output mode of Pulse 1

| Start | L Field | L Field | Start | C Field | A Field | CI Field | data | Check Sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-------------------|-----------|------|
| 68 | 08 | 08 | 68 | 11 | addr | 11 | 01/02/04/05/06/08 | CS | 16 |

Example: (Meter address is 01)
 Master to Slave: 68 04 04 68 11 01 11 **01** 24 16
 Slave to Master: e5

The red-lighted **01** represents the output mode of Pulse1

- 01: Import active energy,
- 02: Import + export active energy,
- 04: Export active energy, (default).
- 05: Import reactive energy,
- 06: Import + export reactive energy,
- 08: Export reactive energy,

15. Read the constant of Pulse 1

| Start | L Field | L Field | Start | C Field | A Field | CI Field | Check Sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----------|------|
| 68 | 03 | 03 | 68 | 11 | addr | 12 | CS | 16 |

Example: (Meter address is 01)

Master to Slave: 68 03 03 68 11 01 12 24 16

Slave to Master: 68 04 04 68 11 01 10 **00** 22 16

The red-lighted **00** represents the constant of Pulse1

- 00: 0.0025kwh (kvarh) / imp (default)
- 01: 0.01kwh (kvarh) / imp
- 02: 0.1kwh (kvarh) / imp
- 03: 1kwh (kvarh) / imp
- 04: 10kwh (kvarh) / imp
- 05: 100kwh (kvarh) / imp

16. Set up the constant of Pulse 1

| Start | L Field | L Field | Start | C Field | A Field | CI Field | data | Check Sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----------------------|-----------|------|
| 68 | 08 | 08 | 68 | 11 | addr | 11 | 00/01/02/03 /04/05 | CS | 16 |

Example: (Meter address is 01)

Master to Slave: 68 04 04 68 11 01 13 **00** 25 16

Slave to Master: e5

The red-lighted **00** represents the constant of Pulse1

- 00: 0.0025kwh (kvarh) / imp (default)
- 01: 0.01kwh (kvarh) / imp
- 02: 0.1kwh (kvarh) / imp
- 03: 1kwh (kvarh) / imp
- 04: 10kwh (kvarh) / imp
- 05: 100kwh (kvarh) / imp

Distributed by:

B+G e-tech GmbH

Franz-Mehring Str. 36

DE 01979 Lauchhammer

T: +49 3574 46755 0

F: +49 3574 46755 19

M: info@bg-etech.de

W: www.bg-etech.de